

**Master Garden Products
Installing Palm and Grass Thatch
Installation Manual
1-800-574-7248**



→ Nylon webbing

1. Unroll the thatch and cut it to size so that it fits the area you want to cover.
2. Always start from the lower edge of the work area, You can staple over the nylon webbing at he top of the thatch.
3. To strengthen the thatch, screw in a strip of wood furring (1" at least) over the nylon webbing .
4. Install the rest of the thatch by overlapping sections, in other words, the bottom edge of the thatch should cover only 6 inches into the subsequent layer.